



WALL TUBES



MOUNTING INSTRUCTIONS FOR SECURITY STANDOFF SYSTEM

Wall Tubes



Hardware




1. Find enclosed hardware and artwork. Toggle anchors, threaded rod, washers, paper template, wooden marking template and glass artwork.
2. Paper templates correspond to glass artwork.




Installation Note

This product must be installed in accordance with the applicable installation code by a person familiar with construction and operation of the product and the hazards involve.

3. Tape paper template to wall according to designers orientation. Use wooden template and pencil to make hole location (find 4 template sizes enclosed)



4. Use small drill bit to drill both holes through template to ensure accuracy. Then remove template and use 1/2" drill bit to enlarge hole for toggle anchor. (drill bits not included)




SOFFI STUDIO

Wall Tube Installation


5. Place and secure toggle anchors, Screw threaded rod leaving 1 1/2" exposed.




6. B Place washers on the threaded rod. Align and place wall tube onto the threaded rod and tighten screw to hold in place.



6A. Secure hardware by closing the gap like so:



8. In the case of tight fitting, the hardware on the bottom end of the Tube can be secured to the wall with a shorter threaded rod



ON CLEANING

Regular cleaning is essential to prevent dust from building up on the glasswork.

For general everyday cleaning, use a soft, antistatic dust brush or similar. For cleaning stubborn layers of dust, use a gentle solvent free cleanser with paper towels or a microfibre cloth. Wipe glass gently.

FOR ETCHED/FROSTED GLASS FINISHES

The piece has been sealed with a special coating for etched glass surfaces. Wipe off any fingerprints of dust with a damp, lint free cloth. Do not immerse in water.

FOR MIRRORED FINISHES

Use a damp, lint free cloth to remove any dust or fingerprints from the outside of the piece. Glass cleaner can be used as well. To clean the inside; DRY dust or air blow ONLY. Any type of chemical or liquid could react with the mirror causing it to oxidize. To clean the inside of the piece, dry dust or use a damp paper towel.

WARRANTY

SOFFI warrants its products to be free of defects in workmanship under normal use and service for a period of one year from the date of purchase. SOFFI reserves the right to inspect damaged product before having any obligation under this limited warranty. All costs of shipping for inspection are the sole responsibility of the purchaser. SOFFI, at its option, shall repair or replace the defective unit covered by this warranty. SOFFI is not responsible for damages caused by improper installation or maintenance. Modifications to the fixture and glass not performed by SOFFI voids the warranty. Our warranty extends to products purchased only by the original purchaser.

GENERAL NOTE

The glass and its hardware should not be exposed to water or wind or be allowed to oscillate continuously in any circumstance. Avoid placing fixtures close to HVAC vents or walls without sufficient bracing to absorb the shock of opening and closing doors.

REPLACEMENTS

Glass replacement parts can be obtained by contacting the studio.

SOFFI STUDIO

Arrangement and Toggle installation instructions

